


Inclinometers

For static applications 1- and 2-axis measurement	IN41	Analog
--	-------------	---------------



Compact. Precise. Versatile.

The IN41 series of inclinometers can reliably detect 2-axis inclinations in a measuring range of $\pm 85^\circ$ or 1-axis inclinations up to 360° . Thanks to their compact housing and high protection class of up to IP68/IP69K, they are also suitable for use in demanding environments. Optionally selectable measuring ranges, integrated filter functions, and various analog interfaces enable flexible adaptation to different applications.



Features and benefits

- **Analog sensor for reliable inclination measurements**
 - 2-axis measurement up to $\pm 85^\circ$ or 1-axis measurement up to 360°
 - Accurate measurement performance across the entire measuring range (up to max. 0.1°)
- **For applications with limited installation space**
 - Economically viable solution with small size
- **Flexible adaptation to versatile applications**
 - Optional selectable measuring ranges and filter functions
 - Various analog interfaces
- **Easy commissioning and diagnostics**
 - LED display for a quick overview of the operating status
 - Individual "Easy-Teach" settings via teach adapter
 - Define preset (zero point/center position)
 - Scaling of the analog measuring range (start/end position)
 - Adjusting the sensor filter
 - Resetting to factory settings
- **For use in harsh environmental conditions**
 - IP68/IP69k protection rating for use in demanding environments
 - Protection against salt spray and rapid temperature changes

Order code 1-axis	8.IN41 . 1 X X 1 . 11 X					
	<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td style="width: 20%;">Type</td> <td style="width: 10%;">a</td> <td style="width: 10%;">b</td> <td style="width: 10%;">c</td> <td style="width: 10%;">d</td> </tr> </table>	Type	a	b	c	d
Type	a	b	c	d		
<p>a <i>Measuring range</i></p> <p>7 = $0^\circ \dots 360^\circ (\pm 180^\circ)$</p> <p>8 = $0^\circ \dots 180^\circ (\pm 90^\circ)$</p>						
<p>b <i>Analog interface</i></p> <p>1 = 4 ... 20 mA</p> <p>2 = 0.1 ... 4.9 V</p> <p>3 = 0.5 ... 4.5 V</p> <p>4 = 0 ... 5 V</p> <p>5 = 0 ... 10 V</p>	<p>d <i>Type of connection</i></p> <p>1 = M12 connector, 8-pin</p> <p>2 = M12 connector, 5-pin</p> <p>3 = cable 8-core, 1 m</p> <p>4 = cable 5-core, 1 m</p> <p>A = cable 8-core, special lengths</p> <p>B = cable 5-core, special lengths</p>					
<p>c <i>Filter</i></p> <p>1 = no filter</p> <p>Preset filter functions up to 10 Hz available on request</p>						

Order code 2-axis	8.IN41 . 2 X X 1 . 11 X					
	<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td style="width: 20%;">Type</td> <td style="width: 10%;">a</td> <td style="width: 10%;">b</td> <td style="width: 10%;">c</td> <td style="width: 10%;">d</td> </tr> </table>	Type	a	b	c	d
Type	a	b	c	d		
<p>a <i>Measuring range</i></p> <p>1 = $\pm 10^\circ$</p> <p>2 = $\pm 15^\circ$</p> <p>3 = $\pm 30^\circ$</p> <p>4 = $\pm 45^\circ$</p> <p>5 = $\pm 60^\circ$</p> <p>6 = $\pm 85^\circ$</p>						
<p>b <i>Analog interface</i></p> <p>1 = 4 ... 20 mA</p> <p>2 = 0.1 ... 4.9 V</p> <p>3 = 0.5 ... 4.5 V</p> <p>4 = 0 ... 5 V</p> <p>5 = 0 ... 10 V</p>	<p>d <i>Type of connection</i></p> <p>1 = M12 connector, 8-pin</p> <p>2 = M12 connector, 5-pin</p> <p>3 = cable 8-core, 1 m</p> <p>4 = cable 5-core, 1 m</p> <p>A = cable 8-core, special lengths</p> <p>B = cable 5-core, special lengths</p>					
<p>c <i>Filter</i></p> <p>1 = no filter</p> <p>Preset filter functions up to 10 Hz available on request</p>						

Inclinometers

For static applications 1- and 2-axis measurement		IN41	Analog
Accessories			Order no.
Teach adapter  	for activating the control inputs for the following functions: - Reset to factory setting - Center point of the measurement - Scaling of the analog measuring range (start/end position) - Setting the sensor filter		
	Teach adapter, 5-pin		05.TX40.1
	Teach adapter, 8-pin		8.0010.9000.0017
EMC shield terminal 	For an EMC-compliant installation of the cable - top-hat rail mounting - spring steel, galvanized - shield diameter 3.0 ... 12.0 mm		8.0000.4G06.0312
Cables and connectors			Order no.
Preassembled cables	M12 female connector with coupling nut, 5-pin, A coded, straight single ended 2 m [6.56'] PVC cable		05.00.6081.2211.002M
	M12 female connector with coupling nut, 5-pin, A coded, straight DT04 connector, male contacts, 6-pin, straight 2 m [6.56'] PVC cable		05.00.6091.22C7.002M
	M12 female connector with coupling nut, 5-pin, A coded, straight single ended 2 m [6.56'] PUR cable		05.00.60F1.2211.002M
	M12 female connector with coupling nut, 8-pin, A coded, straight single ended 2 m [6.56'] PVC cable		05.00.6041.8211.005M
	M12 female connector with coupling nut, 8-pin, A coded, straight single ended 2 m [6.56'] PUR cable		05.00.6051.8211.002M
Connectors	M12 female connector with coupling nut, 8-pin, A coded, straight (metal)		05.CMB 8181-0
	M12 female connector with coupling nut, 5-pin, A coded, straight (metal)		8.0000.5116.0000

Further Kübler accessories can be found at: kuebler.com/accessories



Further Kübler cables and connectors can be found at: kuebler.com/connection-technology

Inclinometers



For static applications 1- and 2-axis measurement	IN41	Analog
--	-------------	---------------

Technical data

General data 1-axis measurement	
Measuring range	0 ... 360°
Resolution	current interface 0.01° internal sensor 12 bit D/A converter voltage interface 12 bit 0 ... 10 V 11 bit 0 ... 5 V / 0.1 ... 4.9 V / 0.5 ... 4.5 V
Repeat accuracy	≤ 0.2 % of the measuring range
Linearity deviation	±0.1 % of the measuring range
Temperature drift	typ. ±0.006 %/K
Accuracy (at 25°C)	±0.1 ... ±0.3° depending on the measuring range



General data 2-axis measurement	
Measuring range	-85° ... +85°
Resolution	current interface 0.01° internal sensor 12 bit D/A converter voltage interface 12 bit 0 ... 10 V 11 bit 0 ... 5 V / 0.1 ... 4.9 V / 0.5 ... 4.5 V
Repeat accuracy	≤ 0.2 % of the measuring range
Linearity deviation	±0.45 % of the measuring range
Temperature drift	typ. ±0.006 %/K
Accuracy (at 25°C)	±0.1 ... ±0.7° depending on the measuring range



Inclinometers

For static applications 1- and 2-axis measurement

IN41

Analog

Electrical characteristics current interface

Supply voltage	10 ... 30 V DC	
Current consumption (no load)	max. 40 mA	
Reverse polarity protection of the supply voltage	yes	
PowerON Time (PowerOn until valid output value)	< 0.5 s	
Output load	at 10 VDC at 24 VDC at 30 VDC	max. 200 Ohm max. 900 Ohm max. 1200 Ohm
Setting time	< 1 ms ($R_{load} = 900 \text{ Ohm}$, 25 °C)	
Sampling rate	50 Hz (20 ms)	
Limit frequency with Butterworth filter	0.1 ... 10 Hz, 8th order	

Mechanical characteristics

Electrical connection	M12 connector, 8-pin M12 connector, 5-pin cable, 8-pin cable, 5-pin	
Weight	approx. 60 g [2.1 oz]	
Protection acc. to EN 60529	IP68/IP69k	
Working temperature range	-40 °C ... +85 °C [-40 °F ... +185 °F]	
Material	housing	plastic, PC
Shock resistance acc. to EN 60068-2-27	100 m/s ² , 10 ... 2000 Hz	
Vibration resistance acc. to EN 60068-2-6	1000 m/s ² , 6 ms	
Dimensions	44.5 x 42.5 x 20 mm [1.75 x 1.67 x 0.79"]	

Electrical characteristics voltage interface

Supply voltage	4 ... 20 mA / 0.1 ... 4.9 V / 0.5 ... 5 V / 0 ... 5 V 0 ... 10 V	10 ... 30 V 15 ... 30 V
Current consumption (no load)	max. 40 mA	
Reverse polarity protection of the supply voltage	yes	
PowerON Time (PowerOn until valid output value)	< 0.5 s	
Output load	max. 10 mA	
Setting time	< 1 ms ($R_{load} = 1000 \text{ Ohm}$, 25 °C)	
Sampling rate	50 Hz (20 ms)	
Limit frequency with Butterworth filter	0.1 ... 10 Hz, 8th order	

Approvals

CE compliant in accordance with		
	EMV Directive	2014/30/EU
	RoHS Directive	2011/65/EU

Inclinometers

For static applications 1- and 2-axis measurement	IN41	Analog
--	-------------	---------------

Terminal assignment, 1 dimensional

Type of connection										M12 connector, 8-pin	
1	Signal – Interface 1 (current):		0 V	+V	Iout+	Iout-	Iout+	Iout-	Teach 1	Teach 2	
	Signal – Interface 2, 3, 4, 5 (voltage):		0 V	+V	Uout+	Uout-	Uout+	Uout-	Teach 1	Teach 2	
	Pin:		1	2	3	4	5	6	7	8	
Type of connection										M12 connector, 5-pin	
2	Signal – Interface 1 (current):		+V	Iout+	0 V	Iout+	Teach				
	Signal – Interface 2, 3, 4, 5 (voltage):		+V	Uout+	0 V	Uout+	Teach				
	Pin:		1	2	3	4	5				
Type of connection										Cable, 8-pin	
3, A	Signal – Interface 1 (current):		0 V	+V	Iout+	Iout-	Iout+	Iout-	Teach 1	Teach 2	
	Signal – Interface 2, 3, 4, 5 (voltage):		0 V	+V	Uout+	Uout-	Uout+	Uout-	Teach 1	Teach 2	
	Core color:		WH	BN	GN	YE	GY	PK	BU	RD	
Type of connection										Cable, 5-pin	
4, B	Signal – Interface 1 (current):		+V	Iout+	0 V	Iout+	Teach				
	Signal – Interface 2, 3, 4, 5 (voltage):		+V	Uout+	0 V	Uout+	Teach				
	Core color:		BN	GY	WH	GN	BU				

Terminal assignment, 2 dimensional

Type of connection										M12 connector, 8-pin	
1	Signal – Interface 1 (current):		0 V	+V	Iout+ X	Iout- X	Iout+ Y	Iout- Y	Teach 1	Teach 2	
	Signal – Interface 2, 3, 4, 5 (voltage):		0 V	+V	Uout+ X	Uout- X	Uout+ Y	Uout- Y	Teach 1	Teach 2	
	Pin:		1	2	3	4	5	6	7	8	
Type of connection										M12 connector, 5-pin	
2	Signal – Interface 1 (current):		+V	Iout+ Y	0 V	Iout+ X	Teach				
	Signal – Interface 2, 3, 4, 5 (voltage):		+V	Uout+ Y	0 V	Uout+ X	Teach				
	Pin:		1	2	3	4	5				
Type of connection										Cable, 8-pin	
3, A	Signal – Interface 1 (current):		0 V	+V	Iout+ X	Iout- X	Iout+ Y	Iout- Y	Teach 1	Teach 2	
	Signal – Interface 2, 3, 4, 5 (voltage):		0 V	+V	Uout+ X	Uout- X	Uout+ Y	Uout- Y	Teach 1	Teach 2	
	Core color:		WH	BN	GN	YE	GY	PK	BU	RD	
Type of connection										Cable, 5-pin	
4, B	Signal – Interface 1 (current):		+V	Iout+ Y	0 V	Iout+ X	Teach				
	Signal – Interface 2, 3, 4, 5 (voltage):		+V	Uout+ Y	0 V	Uout+ X	Teach				
	Core color:		BN	GY	WH	GN	BU				

+V Supply voltage +V DC
 0V Supply voltage ground GND (0 V)
 Teach 1 Input 1 for various teaching functions
 Teach 2 Input 2 for various teaching functions

Uout+ X X axis voltage output
 Uout- X X axis voltage output GND
 Uout+ Y Y axis voltage output
 Uout- Y Y axis voltage output GND

Iout+ X X axis current output
 Iout- X X axis current output GND
 Iout+ Y Y axis current output
 Iout- Y Y axis current output GND

1-axis version
 Uout+ Voltage output
 Uout- Voltage output GND
 Uout+ Inverted voltage output
 Uout- Inverted voltage output GND

1-axis version
 Iout+ Current output
 Iout- Current output GND
 Iout+ Inverted current output
 Iout- Inverted current output GND

Inclinometers


For static applications
1- and 2-axis measurement

IN41

Analog

Dimensions

Dimensions in mm [inch]



Inclinometers

For static applications 1- and 2-axis measurement	IN41	Analog
--	-------------	---------------



Technology in detail

Exact angular position via acceleration measurement

Acceleration measurement


In the acceleration measuring cell, the absolute angular position is determined capacitively in relation to the gravity acceleration \vec{g} .

The displacement **2** of a test mass **1** changes the distance and therefore also the capacity **F** between fixed **3** and moving **4** electrodes in the measuring cell. This measured capacity is directly related to the inclination of the sensor.



Optimization of the measurement using filter functions

The inertia of the test mass, particularly in the case of fast or rapidly changing rotations and vibrations, can lead to inaccuracies in the detected measurement data **b** compared to the actual movement **a**. To compensate for these undesirable effects, various filters **c** + **d** can be parameterized in the inclinometer.



Restrictions due to filters

However, this leads to a time delay ($\Delta t_c + \Delta t_d$) for the output of the measurement result (the more precise the desired measurement, the greater the time delay).

Further optimization with dynamic inclinometers

This time delay is not relevant for many static applications (such as solar panels, crane masts, etc.). In dynamic applications (e.g. vehicles in motion), however, this can lead to problems, as a reaction to the movement can only occur with a delay. In this case, it is advisable to use a dynamic inclinometer IN51 with intelligent sensor fusion from Kübler for further optimization of the measurement result.

Inclinometers

**For static applications
1- and 2-axis measurement**

IN41

Analog

Technology in detail

Quick setting options via the Easy-Teach function with teach adapter

Connection

The teach adapter **2** is connected between the sensor **1** and the connection cable to the application **4**.

Parameterization

The following settings can be made quickly and easily by pressing the toggle switch **3** :

- Reset to factory setting
- Start/end point of the measuring range (for 1-axis measurement)
- Midpoint of the measuring range
- Setting the sensor filter:
no filter, 0.1 Hz, 0.3 Hz, 0.5 Hz, 1.0 Hz, 2.0 Hz, 5.0 Hz or 10.0 Hz

